| | ſ | 1 | | | | Ì | ١ |
|---------------------------------------------------------------|---------|------|----|----|----|----|----|
| | Classic | Plus | K1 | K2 | КЗ | K4 | K5 |
| $@$ Mechanically adjustable variable load training $^{\odot}$ | 0 | 0 | | | | | |
| 🐼 Manually adjustable variable load training 💿 | | | 0 | 0 | 0 | 0 | 0 |
| O Advanced electronic variable load training O | | | 0 | 0 | 0 | 0 | 0 |
| Pressure threshold training ③ | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 📾 Ergonomic design 💿 | | 0 | 0 | 0 | 0 | 0 | 0 |
| (A) Auto-optimising IMT technology | | | 0 | 0 | 0 | 0 | 0 |
| III Graphical history result (36 sessions) ③ | | | | | 0 | 0 | 0 |
| Ci) Single breath test ③ | | | | 0 | 0 | 0 | 0 |
| S Automatic warm-up mode 💿 | | | | | 0 | 0 | 0 |
| S Automatic cool-down mode © | | | | | 0 | 0 | 0 |
| Breathe-Link Software capability ③ | | | | | | 0 | 0 |
| Ø Breathe-Link Import and Export [™] | | | | | | 0 | 0 |
| Seathe-Link Graphical View (2) | | | | | | 0 | 0 |
| Breathe-Link Analytics Pro View © | | | | | | | 0 |
| 😥 Breathe-Link Print Session Detail 💿 | | | | | | | 0 |
| 🚱 Breathe-Link PDF Generator 💿 | | | | | | | 0 |
| O Breathe-Link Custom Mode ③ | | | | | | | 0 |