

BABY CHANGING STATION ON WHEELS

Summary

Series	CROMATIKA
Description	Baby changing unit
Code	PD013
Dimensions	mm. 1920x735x950 H

Description

STRUCTURE:

made of 20 mm thick melamine with a density of about 700 kg per cubic meter in class E1, with low formaldehyde emission in compliance with the UNI EN 120 standard. Enclosure equipped with an anti-dust profile in soft coextruded material on the front edge of the stop. Internal shelves in melamine thickness 20 mm frontally edged with 3 mm ABS profile. Widely radiated. Height adjustable.

DOORS:

made of molded and shaped MDF covered in 20 mm thick technopolymer. Doors equipped with 270 ° opening hinges with easy-grip brushed steel handles. Locks with removable pawl, double folding key and master key.

DRAWERS:

drawer fronts made of molded and shaped MDF covered in 20 mm thick technopolymer. Drawers equipped with painted sheet metal side rails sliding on epoxy resin coated sheet metal guides, with simple sliding on nylon rollers complete with end stop. Drawer bottom in melamine wood fiber and easy-grip satin steel handles.

TOP:

Top made of a single block in postformed ABS complete with rear splashback and perimeter containment edge, complete with padded mattress and 1 pediatric basin sink and mixer with pull-out shower.

CHANGING MAT:

padded and covered in fire-retardant imitation leather in Class 1IM, washable and disinfectable.

BASE:

Base on 4 twin swivel wheels of Ø125mm, each with brake.

